

LANE SOS

FIRST AID KIT
FOR BOWLING LANE MACHINES

**CLICK
BOOK**



bowleasy

CONTENT



KUSTODIAN	4-9
KUSTODIAN PLUS	11-16
KUSTODIAN ION	18-23
KUSTODIAN WALKER (+ION SPORT)	26-31
CROSSFIRE	34-39
IKON (+WALKER)	42-47
FLEX (+WALKER)	50-55



KUSTODIAN	10
KUSTODIAN PLUS	17
KUSTODIAN ION	24-25

KUSTODIAN WALKER (+ION SPORT)	32-33
CROSSFIRE	40-41
IKON (+WALKER)	48-49
FLEX (+WALKER)	56-57

SERVICE PLAN INCLUDING OFFICIAL INSPECTIONS	58-59
NOTES	60-61



LANE CONDITIONERS & CLEANER	62-63
-----------------------------	-------

WEBSHOP.BOWL-EASY.COM



PRODUCT? *31 (0)45 535 03 32

KUSTODIAN

CLEANING



CLEANERTANK ASSY
154-8840



TANKFILTER
154-0212B



O-RING
154-0287C



INLINE FILTER ASSY
154-8867A



RECOVERYTANK
154-8683



RECOVERYTANK FILTER
154-8684



VENT-VALVE
154-8817



SPRAY JET PUMP
158-8213



CUSHIONROLLER w/ CLOTH
164-8839



BODY
153-0217



CAP
153-0218



SCREEN CHECK VALVE
153-0220



OUTSIDE SPRAY TIP
154-0007



INSIDE SPRAY TIP
153-0207



VACUUM M. HOUSING
153-0204H

WEBSHOP.BOWL-EASY.COM



SQUEEGEE BLADE
153-8204E



VACUUM MOTOR
154-8805E



DUSTER MOTOR
153-8803H



SQUEEGEE MOTOR
153-8807H



DUSTER PLUG
153-6853



EASYCLOTH
BEC4

NEW EASYCLOTH (DUSTERCLOTH)

← PIN DECK
PLASTIC ROLL →

INSERT
EASYCLOTH

← CUSHION ROLL
164-8839

DON'T FORGET THE EASYCLOTH (DUSTERCLOTH) RESET ADJUSTMENT!

KUSTODIAN

CONDITIONING



OILTANK w/ FITTING
154-8842



PRESSURE GAUGE
158-1613



VENT-VALVE
154-8817



VALVE OIL CONTROL
154-1209




OILTANK FILTER
154-0212




PUMPHEAD NO MOTOR
154-1214



BELT FOR OILPUMP
154-9215



CONDITIONER TRANS. BRUSH
154-0866



BUFFER BRUSH
154-8641



BUFFER BELT
154-9615



BUFFERMOTOR
154-8616E



BRUSH LIFT MOTOR
153-8807H



OIL PUMP MOTOR
154-8604E



BELT FOR OILHEAD
154-9201



VELCRO SMOOTHING PADS
154-8617V

WEBSHOP.BOWL-EASY.COM

OIL VOLUME TEST!

MENU BUTTON:

AT 'PUMP VOLUME TEST'.

NEXT BUTTON:

UNTIL 'OIL VOLUME TEST #1', SELECT THE PREFERRED PROGRAM BY USING THE ARROW KEYS, THEN TAKE OUT THE OIL TIP, AND PUT IN IN THE GRADUATED CYLINDER.

F6 BUTTON:

PRESS TO START THE CALIBRATION, COMPARE THE VOLUME WITH THE GIVEN NUMBER ON THE OIL PATTERN AND ADJUST WHEN NEEDED.



OIL HEAD TIP ASSY
154-8883 (TRANSFER ROLLER)
154-8851 (TRANSFER BRUSH)
154-8896 (UPGR. TRANS. BRUSH)



SMOOTHING PAD SPRING
153-2540A



PULSE SUPPRESSOR TUBE
154-8816



TO INCREASE THE OIL PRESSURE, TURN THE OIL PUMP IN THE DIRECTION OF THE ARROWHEAD.

KUSTODIAN

CONNECTION & OTHERS



ELBOW 1/4 X 1/4
154-0243



ELBOW 3/8 X 3/8
154-0256



ELBOW 3/8 NPT X 1/4
154-0412



ELBOW 3/8 NPT X 3/8
154-0803



ELBOW 1/4 NPT X 3/8
154-0225



ELBOW 1/4 NPT X 1/4
154-0223



ELBOW 3/8 STEM X 3/8 TUBE
154-0258



ELBOW 3/8 STEM X 1/4 TUBE
158-1214



ELBOW 1/4 STEM X 1/4 TUBE
154-0222



ELBOW 1/8 NPT X 3/16 TUBE
154-0613



MALE SWIVEL ELBOW 1/4 TUBE X 1/4 NPT 153-0818



REDUCING UNION 1/4 X 3/16 154-0248



UNION 1/4 X 1/4
154-0241



UNION TEE 1/4
153-0815



REDUCING UNION 3/8 X 1/4
154-0244

WEBSHOP.BOWL-EASY.COM



UNION TEE 3/8
154-0815



FEMALE CONNECTOR 1/4 X 1/8 FPT
154-0257



2" WHEEL
153-0812S



3" WHEEL
153-0001S



CASTER 2"
153-0812



CASTER 3"
153-0001



GUIDE ROLLER
153-8410



SHOULDER BOLT
153-2407



CABLE FOR KOSI
154-8724BE



MOMENTARY WHEEL
153-7005R



HANDLE REINFORCEMENT KIT 154-8284



LANE DRIVE WHEEL 4"
153-7013



CONVERTER FOR KOSI
157-1057



STRAIGHT TURN LID LATCH
154-0804



FLANGE TURN LID LATCH
154-0805

KUSTODIAN

ELECTRONIC



PLC BATTERY CPM2A
154-1804



POWER CORD ASSY
154-8830 (40 METER)



DRIVEMOTOR
154-8865



SPEED CON. BOARD DRI. MOTOR
153-1812



PLC
154-1801



DISPLAY
154-8806



SENSOR
154-1220



BUFFER CONTRACTOR
153-1604(A)



RELAY
153-1618 (LY3)
154-1611 (LY4)



24V RELAY ASSY
154-1835
OR 154-1835R (RELAY ONLY)



LY2 RELAY
153-1016D 24V
153-1616 230V



SPEED CONTROL BOARD
154-8811



DUSTERSWITCH LARGE
154-1603



BUFFER SQUEEGEE SWITCH 153-1203
154-1015



FUSE HOLDER
153-1028E



PUSH BUTTON
154-8624



E-STOP
154-1250A

KUSTODIAN PLUS

WEBSHOP.BOWL-EASY.COM

CLEANING



CLEANERTANK ASSY
154-8894 (MODEL A)
158-8433C (MODEL B)



TANKFILTER
154-0212B



O-RING
154-0287C



INLINE FILTER ASSY
154-8867A



RECOVERYTANK
158-8434 (MODEL B)
154-8683 (MODEL A)



RECOVERYTANK FILTER
154-8684 (MODEL A)
158-0406 (MODEL B)



VENT-VALVE
154-8817



PUMP
158-8404D



CLEANERPUMP MOTOR
158-8404 (MODEL B) 24V
154-8875 (MODEL A) 230V



SPEED CTR. BOARD CLEANER PUMPMOTOR 154-8848



NORPRENE® TUBING
154-0861B



CUSHIONROLLER w/ CLOTH
164-8839



MALE LUER
154-0863



TIP
164-0012M



CLEANER TIP + CHECK VALVE
154-0862K

WEBSHOP.BOWL-EASY.COM



SQUEEGEE BLADE
153-8204E



VACUUM MOTOR
154-8805E



DUSTER MOTOR
153-8803H



SQUEEGEE MOTOR
153-8807H



CLEANERHEAD DRIVE BELT
154-9201C



VACUUM M. HOUSING
153-0204H



EASYCLOTH
BEC4

← PIN DECK

PLASTIC ROLL →

**INSERT
EASYCLOTH**



← CUSHION ROLL
164-8839

**DON'T FORGET THE EASYCLOTH
(DUSTERCLOTH) RESET ADJUSTMENT!**

KUSTODIAN PLUS

CONDITIONING



**OIL TANK ASSEMBLY
w/ FITTINGS & FLOAT**
154-8682



PRESSURE GAUGE
158-1613



VALVE OIL CONTROL
154-1209



PULSE SUPPRESSOR TUBE
154-8816



OILTANK FILTER
154-0212




PUMPHEAD NO MOTOR
154-1214



BELT FOR OILPUMP
154-9215



CONDITIONER TRANS. BRUSH
154-0866



BUFFER BRUSH
154-8641



BUFFER BELT
154-9615



BUFFER MOTOR
154-8616E



BRUSH LIFT MOTOR
153-8807H



OIL PUMP MOTOR
154-8604E



BELT FOR OILHEAD
154-9201



OIL HEAD TIP ASSY
154-8851

KUSTODIAN PLUS

CONNECTION & OTHERS



ELBOW 1/4 X 1/4
154-0243



ELBOW 3/8 X 3/8
154-0256



ELBOW 3/8 NPT X 1/4
154-0412



ELBOW 3/8 NPT X 3/8
154-0803



ELBOW 1/4 NPT X 3/8
154-0225



ELBOW 1/4 NPT X 1/4
154-0223



ELBOW 3/8 STEM X 3/8 TUBE
154-0258



ELBOW 3/8 STEM X 1/4 TUBE
158-1214



ELBOW 1/4 STEM X 1/4 TUBE
154-0222



ELBOW 1/8 NPT X 3/16 TUBE
154-0613



MALE SWIVEL ELBOW 1/4 TUBE X 1/4 NPT 153-0818



REDUCING UNION 1/4 X 3/16 154-0248



UNION 1/4 X 1/4
154-0241



UNION TEE 1/4
153-0815



REDUCING UNION 3/8 X 1/4
154-0244

WEBSHOP.BOWL-EASY.COM



UNION TEE 3/8
154-0815



FEMALE CONNECTOR 1/4 X 1/8 FPT
154-0257



2" WHEEL
153-08125



3" WHEEL
153-00015



CASTER 2"
153-0812



CASTER 3"
153-0001



GUIDE ROLLER
153-8410



SHOULDER BOLT
153-2407



CONVERTER FOR KOSI
157-1057



6" WHEEL UPGRADE
158-8733



FLOAT SWITCH
154-8693



LANE DRIVE WHEEL 4"
153-7013



PUSH LATCH
154-0881



STRAIGHT TURN LID LATCH
154-0804



FLANGE TURN LID LATCH
154-0805



CABLE FOR KOSI
154-8724BE

OIL VOLUME TEST!

MENU BUTTON:

AT 'PUMP VOLUME TEST'.

NEXT BUTTON:

UNTIL 'OIL VOLUME TEST #1', SELECT THE PREFERRED PROGRAM BY USING THE ARROW KEYS, THEN TAKE OUT THE OIL TIP, AND PUT IN IN THE GRADUATED CYLINDER.

F6 BUTTON:

PRESS TO START THE CALIBRATION, COMPARE THE VOLUME WITH THE GIVEN NUMBER ON THE OIL PATTERN AND ADJUST WHEN NEEDED.

TO INCREASE THE OIL PRESSURE, TURN THE OIL PUMP IN THE DIRECTION OF THE ARROWHEAD.



PLC BATTERY CPM2A
154-1804



POWER CORD ASSY
154-8830 (40 METER)

KUSTODIAN PLUS

ELECTRONIC



DRIVEMOTOR
154-8865



SPEED CON. BOARD DRI. MOTOR
153-1812



PLC (AVAILABLE)
154-1801



DISPLAY
154-8806



SENSOR
154-1220



BUFFER CONTRACTOR
153-1604



LY3 RELAY
153-1618



24V RELAY ASSY
154-1835



LY2 RELAY
153-1016D 24V
153-1616 230V



SPEED CONTROL BOARD
154-8811



DUSTERSWITCH LARGE
154-1603



BUFFER/SQUEEGE SWITCH (S)
153-1203



FUSE HOLDER
153-1028E (MODEL A)
153-1028 (MODEL B)



PUSH BUTTON
154-8624



E-STOP
154-1250A

KUSTODIAN ION

CLEANING



VENT-VALVE
154-8817



NORPRENE® TUBING
154-0861B



PUMP
158-8404D



PUMPMOTOR (24V)
158-8404



**REC. TANK FILTER
10 GALLON** 158-0406



OIL TANK FILTER
154-0212B



RECOVERY TANK FILTER
154-8684



RECOVERY TANK
154-8683 (MODEL A)
158-8434 (MODEL B)



CUSHIONROLLER w/ CLOTH
164-8839



TIP
164-0012M



MALE LUER
154-0863



CLEANER TIP + CHECK VALVE
154-0862K



SQUEEGEE BLADE
153-8204E



CLEANERHEAD DRIVE BELT
154-9201C



VACUUMMOTOR (24V DC)
158-8407

WEBSHOP.BOWL-EASY.COM



DUSTER MOTOR
158-8403



MOTOR F. SQUEEGEE & BRUSHLIFT
158-8402



GASKET FOR 3/4 TANK
154-0832G



CAP WITH GASKET
154-0832



**SPEED CONTROL ASSY
158-8415 (CLEANER)**



INLINE FILTER ASSY
154-8867A



CLEANERTANK ASSY
154-8894 (MODEL A)
158-8433C (MODEL B)



VACUUM M. HOUSING
153-0204H



FLEX. HOSE. REC. TANK
154-0260



SQUEEGEE HOSE
154-6677A

Lane maintenance protects your bowling lanes. So we recommend annual maintenance for the heart of lane maintenance; the lane machine. To guarantee its safety, we can carry out certified inspections for some European countries.

Want to book our maintenance?
info@bowl-easy.com



KUSTODIAN ION

CONDITIONING



WEBSHOP.BOWL-EASY.COM



NEW EASYCLOTH (DUSTERCLOTH)

← PIN DECK

PLASTIC ROLL →

**INSERT
EASYCLOTH**



**DON'T FORGET THE EASYCLOTH
(DUSTERCLOTH) RESET ADJUSTMENT!**

← CUSHION ROLL
164-8839

MISS A PRODUCT? *31 (0)45 535 03 32

KUSTODIAN ION

CONNECTION & OTHERS



CYLINDER FOR CALIBRATION
154-0215A



CABLE FOR KOSI
154-8724BE



CONVERTER FOR KOSI
157-1057



PUSH LATCH
154-0881



ELBOW 1/4 NPT X 3/8
154-0225



ELBOW 1/4 NPT X 1/4
154-0223



ELBOW 3/8 STEM X 3/8 TUBE
154-0258



ELBOW 3/8 STEM X 1/4 TUBE
158-1214



ELBOW 1/4 STEM X 1/4 TUBE
154-0222



ELBOW 1/8 NPT X 3/16 TUBE
154-0613



MALE SWIVEL ELBOW 1/4 TUBE X 1/4 NPT 153-0818



REDUCING UNION 1/4 X 3/16 154-0248



UNION 1/4 X 1/4
154-0241



UNION TEE 1/4
153-0815



REDUCING UNION 3/8 X 1/4
154-0244

WEBSHOP.BOWL-EASY.COM



UNION TEE 3/8
154-0815



FEMALE CONNECTOR 1/4 X 1/8 FPT
154-0257



2" WHEEL
153-0812S



3" WHEEL
153-0001S



STRAIGHT TURN LID LATCH
154-0804



FLANGE TURN LID LATCH
154-0805



GUIDE ROLLER
153-8410



LATCH FOR SPLASH GUARD
154-6357



LID LATCH
153-2232A




LID LATCH
153-2232L

MISS A PRODUCT? *31 (0)45 535 03 32

OIL VOLUME TEST!



TO INCREASE THE OIL PRESSURE, TURN THE OIL PUMP IN THE DIRECTION OF THE ARROWHEAD.



MENU BUTTON:

AT 'PUMP VOLUME TEST'

NEXT BUTTON:

UNTIL 'OIL VOLUME TEST #1', SELECT THE PREFERRED PROGRAM BY USING THE ARROW KEYS, THEN TAKE OUT THE OIL TIP, AND PUT IN IN THE GRADUATED CYLINDER.

F6 BUTTON:

PRESS TO START THE CALIBRATION, COMPARE THE VOLUME WITH THE GIVEN NUMBER ON THE OIL PATTERN AND ADJUST WHEN NEEDED.



PLC BATTERY CPM2A
154-1804



RELAY 24 VDC
158-1420G



RELAY 24 VDC
158-1427

KUSTODIAN ION

ELECTRONIC



DRIVE MOTOR 24V
158-8406



CIRCUIT BOARD ASSY
158-8409



ODYSSEY PC1200 BATTERY
158-8652



RELAY BASE MY4
158-1428



FUSE HOLDER
153-1028



SPEED CONTROL
158-1410



SENSOR
154-1220



ODYSSEY PC925 BATTERY
158-8651



DUSTERSWITCH LARGE
154-1603



PUSH BUTTON
154-8624



OMRON PLC
158-1423



SPEED CON. DRIVE MOTOR
158-8412



RELAY 2 POLE 15A
158-1413



BUFFER/SQUEEGE SWITCH (S)
153-1203



E-STOP
154-1250A

KUSTODIAN WALKER (+ION SPORT)

CLEANING




VENT-VALVE
154-8817



NORPRENE® TUBING
154-0861B



PUMP
158-8404D



PUMPMOTOR (24V)
158-8404



**REC. TANK FILTER
10 GALLON** 158-0406



SUPPLY TANK FILTER
154-0212B



VACUUM M. HOUSING
153-0204H



REC. TANK 10 GALLON
158-8434



CUSHIONROLLER w/ CLOTH
164-8839



TIP
164-0012M



MALE LUER
154-0863



CLEANER TIP + CHECK VALVE
154-0862K



SQUEEGEE BLADE
153-8204E




CLEANERHEAD DRIVE BELT
154-9201C



VACUUMMOTOR (24V DC)
158-8407

WEBSHOP.BOWL-EASY.COM



DUSTER MOTOR
158-8403



MOTOR F. SQUEEGEE & BRUSHLIFT
158-8402



GASKET FOR 3/4 TANK
154-0832G



CAP WITH GASKET
154-0832



FLEX. HOSE. REC. TANK
154-0260



INLINE FILTER ASSY
154-8867A



CLEANERTANK ASSY
158-8433C




SPEED CONTROL ASSY
158-8415 (CLEANER)

MISS A PRODUCT? *31 (0)45 535 03 32

KUSTODIAN WALKER (+ION SPORT)

CONDITIONING



WEBSHOP.BOWL-EASY.COM

NEW EASYCLOTH (DUSTERCLOTH)

← PIN DECK

PLASTIC ROLL →

INSERT EASYCLOTH

DON'T FORGET THE EASYCLOTH (DUSTERCLOTH) RESET ADJUSTMENT!



← CUSHION ROLL
164-8839



KUSTODIAN WALKER (+ION SPORT)

CONNECTION & OTHERS



CYLINDER FOR CALIBRATION
154-0215A



CABLE FOR KOSI
154-8724BE



CONVERTER FOR KOSI
157-1057



LATCH w/ KEY LOCK
154-0881



ELBOW 1/4 NPT X 3/8
154-0225



ELBOW 1/4 NPT X 1/4
154-0223



ELBOW 3/8 STEM X 3/8 TUBE
154-0258



ELBOW 3/8 STEM X 1/4 TUBE
158-1214



ELBOW 1/4 STEM X 1/4 TUBE
154-0222



ELBOW 1/8 NPT X 3/16 TUBE
154-0613



MALE SWIVEL ELBOW 1/4 TUBE X 1/4 NPT
153-0818



REDUCING UNION 1/4 X 3/16
154-0248



UNION 1/4 X 1/4
154-0241



UNION TEE 1/4
153-0815



REDUCING UNION 3/8 X 1/4
154-0244

WEBSHOP.BOWL-EASY.COM



UNION TEE 3/8
154-0815



FEMALE CONNECTOR 1/4 X 1/8 FPT
154-0257



2" WHEEL
153-0812S



3" WHEEL
153-0001S



STRAIGHT TURN LID LATCH
154-0804



FLANGE TURN LID LATCH
154-0805



GUIDE ROLLER
153-8410



LATCH FOR SPLASH GUARD
154-6357



PUSH LATCH
154-0881



FLEX. HOSE. REC. TANK
154-0260



CONNECTOR MALE
154-0232D



DRIVE MOTOR BRUSHES
158-1405B



REAR GUIDE WHEEL
158-8636 (SPORT)



FRONT GUIDE WHEEL
158-8637 (SPORT)



WHISKER ASSY
158-8623



FLOAT SWITCH
154-8693

MISS A PRODUCT? *31 (0)45 535 03 32

KUSTODIAN WALKER (+ION SPORT)

ELECTRONIC



		
CONDITIONING MOTOR 158-8401A	SPEED CONTROL DRIVE 158-1410	PUMPMOTOR (24V) 158-8404
		
MOTOR F. SQUEEGEE & BRUSHLIFT 158-8402	SENSOR 154-1220	MICROSWITCH W/ ROLLER 154-1015
		
ODYSSEY PC1200 BATTERY 158-8652	ODYSSEY PC925 BATTERY 158-8651	RELAY 2 POLE 15A 158-1413
		
24V DC DPDT 158-1458	DUSTERSWITCH LARGE 154-1603	BUFFER/SQUEEGE SWITCH (S) 153-1203
		
VACUUMMOTOR (24V DC) 158-8407	DUSTER MOTOR 158-8403	E-STOP 154-1250A

WEBSHOP.BOWL-EASY.COM

		
MICROSWITCH NO ROLLER 153-1202	RELAY 158-1420G	RELAY 24 VDC 158-1427
		
SPEED CONTROL ASSY 158-8415 (CLEANER)	BASE (RELAY) 158-1461	RELAY 158-1462
		
SPEED CON. DRIVE MOTOR 158-8412	SPEED CONTROL 158-1605 (SPORT)	BATTERY PACK 158-8631 (SPORT)
		
		PLC BATTERY CPM2A 154-1804 (WALKER A/B)

Lane maintenance protects your bowling lanes. So we recommend annual maintenance for the heart of lane maintenance; the lane machine. To guarantee its safety, we can carry out certified inspections for some European countries.

Want to book our maintenance?
info@bowl-easy.com



MISS A PRODUCT? +31 (0)45 535 03 32

CROSSFIRE

CLEANING



CLEANERTANK ASSY
154-8840



SUPPLY TANK FILTER
154-0212B



O-RING
154-0287C



INLINE FILTER ASSY
154-8867A



RECOVERYTANK
153-8841



RECOVERYTANK FILTER
153-8841



VENT-VALVE
154-8817



SPRAY JET PUMP
158-8213



CUSHIONROLLER w/ CLOTH
164-8839



BODY
153-0217



CAP
153-0218



SCREEN CHECK VALVE
153-0220



OUTSIDE SPRAY TIP
154-0007



INSIDE SPRAY TIP
153-0207A



KIT
154-8692

WEBSHOP.BOWL-EASY.COM



SQUEEGEE BLADE
153-8204E



VACUUMMOTOR
158-8208E



DUSTERMOTOR
153-8803H



SQUEEGEEMOTOR
153-8807H



EASYCLOTH
BEC4

NEW EASYCLOTH (DUSTERCLOTH)

← PIN DECK

PLASTIC ROLL →

INSERT EASYCLOTH

← CUSHION ROLL
164-8839

DON'T FORGET THE EASYCLOTH (DUSTERCLOTH) RESET ADJUSTMENT!

CROSSFIRE

CONDITIONING



WICK
153-0005B



VENT-VALVE
154-8817




OILTANK FILTER
154-0212 (8 PAD MACHINE)



TRANSFER ROLLER MOTOR
153-8829



SPRING WICK PLATE
153-2740



BUFFER BRUSH
154-8641



BUFFER BELT
158-9201



BUFFERMOTOR
154-8616E




BRUSH LIFT MOTOR
153-8807



CONDITIONING CAP FITTING 158-0201

@WICK PARTS:
WE RECOMMEND YOU TO
CREATE THE WICK PIECE YOU
NEED BY PURCHASING OUR
WICK (153-0005B).

WEBSHOP.BOWL-EASY.COM



MISS A PRODUCT? *31 (0)45 535 03 32

CROSSFIRE

CONNECTION & OTHERS



ELBOW 1/4 X 1/4
154-0243



ELBOW 3/8 X 3/8
154-0256



ELBOW 3/8 NPT X 1/4
154-0412



ELBOW 3/8 NPT X 3/8
154-0803



ELBOW 1/4 NPT X 3/8
154-0225



ELBOW 1/4 NPT X 1/4
154-0223



ELBOW 3/8 STEM X 3/8 TUBE
154-0258



ELBOW 3/8 STEM X 1/4 TUBE
158-1214



ELBOW 1/4 STEM X 1/4 TUBE
154-0222



ELBOW 1/8 NPT X 3/16 TUBE
154-0613



MALE SWIVEL ELBOW 1/4 TUBE X 1/4 NPT 153-0818



REDUCING UNION 1/4 X 3/16 154-0248



UNION 1/4 X 1/4
154-0241



UNION TEE 1/4
153-0815



REDUCING UNION 3/8 X 1/4
154-0244

WEBSHOP.BOWL-EASY.COM



UNION TEE 3/8
154-0815



FEMALE CONNECTOR 1/4 X 1/8 FPT
154-0257



2" WHEEL
153-0812S



3" WHEEL
153-0001S



CASTER 2"
153-0812



CASTER 3"
153-0001



GUIDE ROLLER
153-8410



SHOULDER BOLT
153-2407



LANE DRIVE WHEEL 4"
153-7013



FLANGE TURN LID LATCH
154-0805



STRAIGHT TURN LID LATCH
154-0804

MISS A PRODUCT? *31 (0)45 535 03 32



BATTERY PLC (TWIDO)
155-1246

CROSSFIRE

ELECTRONIC



DRIVEMOTOR
154-8865



SPEED CONTROL CROSSFIRE
158-1212R



TWIDO TO CP1L UPGRADE
158-8255



DISPLAY
154-8806 (OMRON ONLY)



SENSOR / XFA
154-1220 / 158-1208



BUFFER CONTRACTOR
153-1604(A)



LY3 RELAY 230 V
153-1618



LY2 RELAY 230 V
153-1616



LY2 RELAY 24V
153-1016D



SWITCH (W/O ROLLER)
153-1202



BUFFER/SQUEEGE SWITCH (S)
153-1203



FUSE HOLDER
153-1028E



PUSH BUTTON
154-8624




E-STOP
154-1250A



POWER CORD ASSY
154-8830 (40 METER)

IKON (+WALKER)

CLEANING



WEBSHOP.BOWL-EASY.COM


NEW EASYCLOTH (DUSTERCLOTH)

← PIN DECK
PLASTIC ROLL →

INSERT
EASYCLOTH

← CUSHION ROLL
164-8839

DON'T FORGET THE EASYCLOTH (DUSTERCLOTH) RESET ADJUSTMENT!



IKON (+WALKER)

CONDITIONING



PULSE SUPPRESSION ASSEMBLY
154-8816



PRESSURE GAUGE
158-1613



OIL CONTROL VALVE
154-1209



VENT-VALVE
154-8817



OIL TANK ASSEMBLY w/ FITTINGS & FLOAT
154-8682



OIL TANK FILTER
154-0212



FLOAT SWITCH ASSEMBLY
154-8693



BELT FOR CONDITIONER PUMP MOTOR
154-9202A



BUFFER TACH BELT
154-9203



OIL TANK CAP ASSEMBLY GASKET ONLY 164-0021



PUMPHEAD NO MOTOR
154-1214



CONDIT. SYSTEM TUBING 3/16" 154-0202B



CONDIT. SYSTEM TUBING 1/4" 154-0202A



CONDIT. SYSTEM TUBING 3/8" 154-0202



HEAD DRIVE BELT
154-9201

WEBSHOP.BOWL-EASY.COM



OIL HEAD TIP ASSY
154-8851



FLEX. HOSE. REC. TANK
154-0260



SPRING OIL TIP
153-2713



SINGLE CONDITIONER TRANSFER BRUSH ASSY
164-0866



OIL LINE SPRING
154-0206



BUFFER BRUSH
164-8001A



LEFT WHISKER ASSY
164-8824 (WALKER)



RIGHT WHISKER ASSY
164-8825 (WALKER)

MISS A PRODUCT? *31 (0)45 535 03 32

IKON (+WALKER)

CONNECTION & OTHERS



SPEED CONTROL BOARD
164-8807



MAIN DRIVE CHAIN
154-9601 (40P41)



FLUSH MOUNT LID LATCH
153-2232L (WITH LOCK)



ELBOW 1/4 X 1/4
154-0243



ELBOW 3/8 X 3/8
154-0256



ELBOW 3/8 NPT X 1/4
154-0225



DRIVE MOTOR WALKER
164-8602A (RIGHT) 4.25" SHAFT
164-8602 (LEFT) 2.5" SHAFT
164-1246 BRUSHES



DRIVE MOTOR 24V
158-8406 DRIVE MOTOR
158-1405B BRUSHES



SQUEEGEE HOSE
154-6677A



ELBOW 1/4 NPT X 1/4
154-0223



ELBOW 1/4 STEM X 1/4 HOSE
154-0226



ELBOW 1/4 STEM TO 5/16 HOSE
154-0227



ELBOW 3/8 STEM X 3/8 TUBE
154-0258



ELBOW 1/4 STEM X 1/4 TUBE
154-0222



REDUCING UNION 1/4 X 3/16
154-0248

WEBSHOP.BOWL-EASY.COM



UNION 1/4 X 1/4
154-0241



FEM. CONNECTOR 1/4 TUBE X 1/8 FPT
154-0257



HANDLE MOUNT KIT
164-8253



COMPLETE SQUEEGEE CARTRIDGE ASSEMBLY
164-8038



DUSTER MICROSWITCH WITH ROLLER
153-1203



WHEEL
153-7005R



LANE TO LANE 3" CASTER
164-0022



WHEEL ASSY
158-7002



3" WHEEL
153-0001S



DUSTER MICROSWITCH (L)
154-1603



GUIDE ROLLER
153-8410

IKON (+WALKER)

ELECTRONIC



KEGEL K2 E. BATTERY
158-1634B (62 LANES)



24V DC DPDT
158-1458



SOLID SNAKE
158-1460



SUPER MY4 24V DC
158-1463 (WITH DIODE)



CABLE FOR KOSI
154-8724BE



BUTTON ASSY
164-8013



FUSE 25A CVR
158-1439



CONVERTER FOR KOSI
157-1057



E-STOP
164-1223



CONTACTOR
158-1465



DUSTER MICROSWITCH (L)
154-1603



COND. PUMP MOTOR 24V DC
158-8401A



MOTOR BRUSH FOR COND. GROSCHOPP (GRAY)
158-1422G



HEAD DRIVE MOTOR
158-8405 (24V DC)



VACUUMMOTOR (24V DC)
158-8407

WEBSHOP.BOWL-EASY.COM



BRUSH LIFT MOTOR
158-8402



BUFFER MOTOR 24V DC
158-8414



DUSTER MOTOR ASSY 24V
158-8403



RELAY
158-1462



CP1H PLC (w/o PORTS)
158-1610P



DUSTER MICROSWITCH WITH ROLLER
153-1203



SPRAYLESS CLEANER PUMP
158-8404



PROXIMITY SENSOR
154-1220



SPEED CONTROL
164-8806 (CLEANER)



FUSE HOLDER
153-1028

FLEX (+WALKER)

CLEANING



VACUUMMOTOR (24V DC)
158-8407



CLEANER TUBING ASSY
164-8026 #16 CONCENTRATED



CLEANER TUBING ASSY
164-8025 #14 SUPER CONCENTRATED



INLINE FILTER ASSY
154-8867A



RECOVERYTANK FILTER
164-8017F



VACUUM M. HOUSING
153-0204H



SQUEEGEE BLADE
153-8204E



CLEANER TIP HOSE ASSY
154-8852



CUSHIONROLLER w/ CLOTH
164-8839



CLEANER TIP
164-0012M



MALE LUER 1/8" HOSE BARB
154-0863



OIL TANK CAP ASSEMBLY COMPLETE
164-8081



FLOAT SWITCH
154-8693



SUPPLY TANK FILTER
154-0212B



CLEANER PUMP ASSY
158-8404D

WEBSHOP.BOWL-EASY.COM



NORPRENE® TUBING
154-0861B



SQUEEGEE GASKET
164-0003



REC. TANK FILTER
164-6114

MISS A PRODUCT? *31 (0)45 535 03 32

FLEX (+WALKER)


CONDITIONING




TIMING BELT
164-9006 (FLX-17732 / FXW113228 AND BELOW)



PRESSURE GAUGE
158-1613



BUFFER MOTOR BELT
154-9615 (FLX117733 / FXW113229 AND ABOVE) VB



BUFFERBRUSH
164-8001 (FXW/FLX)
164-8001A (FW/FX)




HEAD DRIVE BELT
154-9201



OIL TANK FILTER
154-0212



FLOAT SWITCH ASSEMBLY
154-8693



BUFFERBELT NON VB
164-9016 (352L050 FW/FX)




BELT FOR BUFFER
154-9203




OIL TANK CAP ASSEMBLY GASKET ONLY 164-0021



FLUID METERING OIL PUMP
154-1214



CONDIT. SYSTEM TUBING
3/16" 154-0202B



CONDIT. SYSTEM TUBING
1/4" 154-0202A



CONDIT. SYSTEM TUBING
3/8" 154-0202



SUBTANK O-RING
164-6173

WEBSHOP.BOWL-EASY.COM



SPRING TIP RETAINER
153-2713



PULSE SUPPRESSION
164-8021



BUFFERBELT VB
164-9017 (356L050 FW/FX)



SINGLE CONDITIONER TRANSFER BRUSH ASSY
164-0866

MISS A PRODUCT? *31 (0)45 535 03 32

FLEX (+WALKER)

CONNECTION & OTHERS



UNION 1/4 X 1/4
154-0241



FEM. CONNECTOR 1/4 TUBE X 1/8 FPT
154-0257



CONVERTER FOR KOSI
157-1057



VACUUM M. HOUSING
153-0204H



ELBOW 3/8 X 3/8
154-0256



FLEX. HOSE. REC. TANK
154-0260



ELBOW 1/4 X 1/4
154-0243



ELBOW 3/8 X 3/8
154-0256



ELBOW 3/8 NPT X 1/4
154-0225



ELBOW 1/4 NPT X 1/4
154-0223



ELBOW 1/4 STEM X 1/4 HOSE
154-0226



ELBOW 1/4 STEM TO 5/16 HOSE
154-0227



ELBOW 3/8 STEM X 3/8 TUBE
154-0258



ELBOW 1/4 STEM X 1/4 TUBE
154-0222



REDUCING UNION 1/4 X 3/16
154-0248

WEBSHOP.BOWL-EASY.COM



LID PIVOT ARM LH
164-6101



LID PIVOT ARM RH
164-6100



FLUSH MOUNT LID LATCH
153-2232L (WITH LOCK)



COMPLETE SQUEEGEE
CARTRIDGE ASSEMBLY
164-8038



GUIDE ROLLER
153-8410



WHEEL
153-7005R



LANE TO LANE
3" CASTER
164-0022



CABLE FOR KOSI
154-8724BE



3" WHEEL
153-0001S



DUSTER MICROSWITCH (L)
154-1603



WHEEL ASSY
158-7002



DUSTER MICROSWITCH
WITH ROLLER
153-1203



PROXIMITY SENSOR
154-1220

FLEX (+WALKER)

ELECTRONIC



KEGEL K2 E. BATTERY
158-1634B (62 LANES)



SPEED CONTROL ASSY
158-8415 (CLEANER)



RELAY
158-1462



SUPER MY4 24V DC
158-1463 (WITH DIODE)



SPEED CONTROL
158-1605 (OIL/CLEANHEAD)



REPLACEMENT BATTERY
158-1634C (90 LANES)



VACUUM MOTOR (24V DC)
158-8407



STEPPER MOTOR ASSY
158-8632



SPEED CONTROL BOARD
158-1410



CONTACTOR
158-1465



FUSE HOLDER
153-1028



COND. PUMP MOTOR 24V DC
158-8401A



MOTOR BRUSH FOR COND. GROSCHOPP (GRAY)
158-1422G



OIL CONTROL VALVE
154-1209



MOTOR BRUSH FOR COND. HEAD MOTOR 158-1404B

WEBSHOP.BOWL-EASY.COM



BRUSH LIFT MOTOR
158-8402



BUFFER MOTOR 24V DC
158-8414 (STANDARD)
164-8014 (VARIABLE SPEED UPGR.)



DUSTER MOTOR ASSY 24V
158-8403



SPRAYLESS CLEANER PUMP
158-8404



CP1H PLC (w/o PORTS)
158-1610P

Lane maintenance protects your bowling lanes. So we recommend annual maintenance for the heart of lane maintenance; the lane machine. To guarantee its safety, we can carry out certified inspections for some European countries.

Want to book our maintenance?
info@bowl-easy.com





SERVICE PLAN

DATE	DESCRIPTION	NAME

BOWLING INSPECTIONS:

NL
NEN 3140

DE
Elektroprüfung gemäß
BetrSichV / DGUV Vorschrift 3


DATE	DESCRIPTION	NAME

RECOMMENDED REPLACEMENTS OF SPARE PARTS IN MONTHS

	#LANES	12	16	24	32	40
BRUSH SET FOR BALDOR DC MOTOR (154-1809B)	48	48	36	24	18	
SQUEEGEE BLADES (TURN HALFWAY 180°) (153-8204E)	24	20	18	12	12	
TRANSFER BRUSH ASSEMBLY (154-0866)	36	36	30	24	18	
BUFFER BRUSH ASSEMBLY (154-8641)	24	24	18	15	12	
CUSHION ROLLER ASSEMBLY (164-8839)	24	18	12	12	12	



NOTES



WEBSHOP.BOWL-EASY.COM



bowleasy's
LANE LEGENDS



LANE CONDITIONERS
& CLEANER



WEBSHOP CODE: BEEMP

EMPIRE
LANE CONDITIONER
38 VISCOSITY
SPORT BOWLING



EasyCloth

WEBSHOP CODE: BEC4




WEBSHOP CODE: BECRO

CROWN
LANE CONDITIONER
50 VISCOSITY
SPORT BOWLING

WEBSHOP CODE: BEOPT

OPTIMUM
LANE CONDITIONER
31 VISCOSITY
RECREATIONAL

BOWLING



WEBSHOP CODE: BEPUL

PULSE
LANE CONDITIONER
27 VISCOSITY
RECREATIONAL

BOWLING

KEEP BOOKLET
IN/NEAR
LANE MACHINE

